KTF-S Single Board Wiring Manual v3.0


Interface definition:

Alarm interface:

- 1.Alarm in
- 2.Alarm in GND
- 3.Alarm out
- 4.Alarm out GND

Function interface:

Connect to the motherboard SDIO Port



Reserved-Onboard storage:

(Customized function)

Reserved-battery

position:

(Need to be customized)

TF card socket:

Maximum support 256GB micro-SD



<u>sales@smtsec.com</u> www.smtsec.com